

Air Conditoner Disconnect

Air Conditioner disconnect application

The purpose of A/C disconnect is offer a visiable solution to prevent un-authorized person from hurting by A/C (air conditioning) system circuit when house owner left their house for a certain period, they will lock the A/C disconnect when leaving, and they are installed out-door. NEMA 3R rain-proof.

Model	Rated Current(A)	Rated Voltage(V)	Phase	No. of Fuses	No. of Wires	Case Qty.(Pcs)	Approval
SDB-60NF	60	240	1 P	None	2 Wires	12	cULus
SDB-60F	60	240	1 P	2	2 Wires	12	cULus
SDB-30F	30	240	1 P	2	2 Wires	12	cULus
TDB-60NF	60	240	1 P	None	2 Wires	12	cULus

SDB-60NF

SDB-60F

SDB-30F

TDB-60NF



SDB-60NF

Model fuse holder

SDB-60F


Model fuse holder

SDB-30F

Model fuse holder

TDB-60NF

Model fuse holder



SDB-60NF

SDB-60F

SDB-30F

TDB-60NF

